

activiva

Metal Aroma Diffuser

User Manual



ACA-AD-M1 / ACA-AD-M2

1. Please read this manual carefully before using the product, and retain this manual for future reference.
2. Risk of fire hazard and forbidden to put in water and against electric shock, Only rated for indoor use.
3. Product designed for consumer and household application only.
4. No user serviceable parts inside; warranty void opened by non-authorized personnel.

IMPORTANT

1. This product is for indoor use only; do not operate outdoors.
2. Always place unit on a smooth, flat, lint-free, non-metallic, waterproof and level surface.
3. Always have water in the diffuser when operating; do not operate without water.
4. Always use only clean, cool water to fill the base; do not use hot water.
5. Always unplug the diffuser when cleaning, moving the unit or when not in use.
6. Avoid operating the diffuser with wet hands to avoid electric shock.
7. Avoid moving the diffuser once it has been filled with water.
8. Avoid positioning the diffuser in direct sunlight.
9. Avoid positioning power cord on heated surfaces and areas of access to avoid tripping/trampling.
10. Do not leave the diffuser unattended while in operation.
11. Do not pour water into any openings other than the base.
12. Do not cover any openings on the unit or insert objects into any openings.
13. Do not aim mist directly at children, pets, walls, furniture or electrical appliances.
14. Do not operate the diffuser with a damaged cord or plug.
15. Do not operate the diffuser
16. Clean and maintain the diffuser regularly to ensure smooth operation.
17. Clean with water only; do not use detergents, solvents or abrasive agents for cleaning.
18. Do not tilt, tip or attempt to empty or fill the diffuser during operation.

For more FAQs and information, visit:


<http://www.mbeat.com.au/support>

Email: support@mbeat.com.au


INSTRUCTION



1. Connect power. *Only use package included DC Power Adapter with this product.



2. Add water to the base, do not exceed MAX line (260 ml). Add a few drops of essential oil of your choice. *Always use water soluble oil.




3. Close the top and replace the metal cover.




4. Press  button to start MIST
Press  button to start LIGHT

WHEN EMPTYING DIFFUSER...



Pour water away from Air Outlet



Pouring on the wrong side may cause water to enter the Air Outlet

SPECIFICATIONS

Material: Metal, ABS

Diffuser capacity: 260 ml

Color changing mode: 7 colour LED

Time setting: Auto / 1H / 3H / 5H



Auto stop misting: Up to 10 hrs

Product dimensions: 11.7×11.7×19.6 cm

Product weight: 0.59 kg

Package contents: Aroma diffuser, user manual, measuring cup and DC power adapter

FUNCTIONS

BUTTON	MODES
 Mist	4 Time Setting Modes: Auto / 1H / 3H / 5H
 Light	Press once to activate colour cycle mode. Press again to lock-in 1 of 7 colours. Press and hold for 3 seconds to turn off.

Note: Diffuser and light will shut off automatically when water runs out.

TROUBLESHOOTING INSTRUCTIONS

The diffuser is not misting/there is very little mist/intermittent misting:

- Make sure the power is connected.
- Make sure to keep water level below the MAX line.
- Make sure the mist outlet is aligned with the cover and not blocked.
- Water outlet blocked by oils; use water soluble oils or clean water outlet with a cotton swab.
- Too much oil in water; make sure to only use a few drops to prevent oil bubbles from forming, prohibiting water from diffusing.